PASSIVE Q-SWITCHES




Fe²⁺:ZnSe and Fe²⁺:ZnS PASSIVE Q-SWITCHES


Fe²⁺:ZnSe and Fe²⁺:ZnS saturable absorbers (SA) are ideal materials for passive Q-switches of solid-state lasers operating in the spectral range of 2.5-4.0 μ m.

These lasers (e.g. 3.0 µm Er:YAG/YSGG/YLF) are used for pumping middle-infrared Optical Parametric Oscillators and for numerous medical and dental applications.


IPG's fabrication process allows low cost mass production of a very large variety of diffusion-doped Fe²⁺:ZnSe/Zns crystals with low losses, uniform distribution of iron, good reproducibility and reliability.



Samples of Fe²⁺:ZnSe Single and Polycrystalline Saturable Absorbers



Absorption Spectra of Fe²⁺:ZnS & Fe²⁺:ZnSe Saturable Absorbers



Experimental Results for Transmission vs. Fluence in Fe:ZnSe (circles) Numerical fit for $\sigma_{nsa} = 0.6x10^{-18}~cm^2~at~2.8~\mu m~(solid~line)$



Fe²⁺:ZnS and Fe²⁺:ZnS Passive Q-Switches

Crystal	Peak coefficient absorption, cm ⁻¹	Upper level lifetime at 300K, µS	σ _{gsa} at 2.8 μm, 10 ⁻²⁰ cm ²	$\sigma_{ m gsa}/\sigma_{ m esa}$	$\sigma_{gsa}/\sigma_{YSGG}$
Fe:ZnSe	1-20	0.37	90	0	30
Fe:ZnS	1-20	< 0.3	130	0	43

According to the criterion for Saturable Absorber Q-switching:

$$\frac{\sigma_{Qgsa}}{\sigma_{YSGG}} \times \frac{A_{YSGG}}{A_Q} > 1$$

Fe:ZnSe/S can be used as a saturable absorber Q-switch for the Cr:Er:YSGG laser without intracavity focusing.

Output energies of 15 and 85 mJ were achieved in single and multipulse modes of operation, respectively.

The combination of

- high values of saturation cross-section,
- small saturation energy with good opto-mechanical (damage threshold 2 J/cm²) and
- physical characteristics of ZnSe and ZnS hosts

makes Fe²⁺:ZnSe/S crystals an ideal market for passive Q-switching of mid-infrared laser cavities.

Legal notices: All product information is believed to be accurate and is subject to change without notice. Information contained herein shall legally bind IPG Photonics only if it is specifically incorporated into the terms and conditions of a sales agreement. Some specific combinations of options may not be available. The user assumes all risks and liability whatsoever in connection with use of a product or its application. IPG Photonics and IPG Photonics logo are trademarks of IPG Photonics Corporation. Other trademarks are property of their respective holders. © 2010 IPG Photonics Corporation. All rights reserved. Protected by US Patents 5,541,948; 6,960,486; 7,548,571 and applicable licenses

IPG Photonics Mid-Infrared Lasers +1 205.307.6677; Fax +1 205.307.6688 sales.ipgm@ipgphotonics.com www.ipgphotonics.com/midIR